



7.

2 ENTRANCE HALLS (with wiring)

UP TO 1,000 NAMES



HOW THE INSTALLATION WORKS

- The residents' badges open their entrance hall.
- Visitors call residents using the intercom.
- The residents open the door to their entrance hall using the ★ key on their telephone (for example).

EQUIPMENT REQUIRED

- 1 complete pack with intercom and 1,000-name central unit (cf. p. 33 and p. 35),
- 1 intercom only (cf. p. 32 and p. 34),
- 1 extension card (cf. p. 48),
- 1 3G block included in the INTRATONE TELECOM package, 3G module(s) supplied on subscription to the contract.

N.B. No remote video camera.

Power supply to be wired as close as possible to the central unit.

Max. distance of 100 m between each unit with 0.8 mm twisted cable.

TECHNICAL SUPPORT: export@intratone.com / +33 (0) 251 655 529

Remote management site: www.intratone.com