



# SET UP AN INTRABOX DATA ECO (1/2)




**A1** Check that the current page is **<Residence, district>**.

**A2** Click on one of the **<Create>** buttons, they are all similar.



**A4** Click on the **<Create>** button in front of the product INTRABOX DATA ECO.

## SET UP AN INTRABOX DATA ECO (2/2)



- |           |   |
|-----------|---|
| <b>A5</b> | Enter the contract number indicated on the document supplied with the GPRS module.  |
| <b>A6</b> | Click on <input type="button" value="🔍"/> .   |
| <b>A7</b> | Enter the serial number of the central unit 03-0102-XX (EXX-CIC12) if it is included in the kit.                                |
| <b>A8</b> | Enter the name of the access to identify it in the residence<br><i>EX : front door, bin door, main gate, garage door etc...</i> |
| <b>A9</b> | Click on <b>&lt;Save&gt;</b>  |

**Note :**

If the residence structure is "complete", it is possible to create :

- A main entrance : The entrance permits to access to all blocks.
- A secondary entrance : The entrance permits to access to the block associated.