


Instructions for connecting the keypad and proximity reader to the central unit



Example of cabling of the proximity reader keypad to connector 1



Recessed box

